




- 1 (A) Seat Assembly
- 1 (B) Back Assembly
- 2 (C) Glider Base
- 2 (D) Bearing Arm Supports
- 14 (E) Back Slats
- 2 (F) Armrest's
- 2 (G) Front-Back Crosspieces
- 2 (H) Crosspiece Supports
- 2 (I) Lintels



1. Attach (G) Front-Back Crosspieces to (C) Glider Base's Using 14 - 2" Screws per side, be sure to match all numbers & or letters.




2.Attach (H) Crosspiece Supports to Front-Back Crosspieces using 4 - 2" Screws per side, be sure to match all numbers & or letters.



3. Attach (D) Bearing Arm Supports to Glider Base using 4 - 2 1/2" Screws per side, be sure to match all numbers



4. Attach (F) Armrests to Glider Base using (2-Washers)&(2-Nuts) per side, be sure to match all numbers & or letters. "Assembly order is Armrest Assembly-Washer-Nut"






R.M.


10/16/2017



5. Attach (E) Back Slats to (B) Back Assembly using 4 - 1 1/2" Screws per slat, be sure to match all numbers & or letters.




6. Attach Back Assembly to (A) Seat Assembly using 6 - 2" Wafer Bolts, be sure to Match all numbers & or letters, tighten Wafer Bolts with included Hex Key.




7. Attach Back-Seat Assembly to Armrests using

- 1 3 1/2" Wafer Bolt
- 1 2 1/2" Wafer Bolt &
- 1 2" Wafer Bolt

per side,be sure to match all numbers & or letters, tighten Wafer Bolts with included Hex Key.



8. Attach (I) Lintels to Armrest Assemblies using 4 - 2" Screws per side, be sure to match all numbers & or letters.





5' Adirondack Poly Glider Assembly Instructions

10/16/ 2017

R.M.